





Device Positions

8-pin PIC



PIC12C508/508A/509/509A
 PIC12C671/672
 PIC12CE518/519/673/674
 PIC12F508/509/510
 PIC12F615/HV615
 PIC12F629/635/675/683



14-pin PIC




PIC16F616/HV616
 PIC16F630/636/676/684/688

PIC16F505/506

18-pin PIC





PIC16C620A/621A/622A
 PIC16CE623/624/625
 PIC16F54
 PIC16C710/711/712/715/716
 PIC16F716
 PIC16F84/84A
 PIC16F818/819
 PIC16F87/88
 PIC18F1220/1230/1320/1330





PIC16F627/627A/628/628A/648A
 PIC16F818/819 (INTRC)

20-pin PIC





PIC16F631/639/677
 PIC16F685/687
 PIC16F689/690/785

28-pin PIC



PIC16C62B/63A/642/66
 PIC16C72A/73B/745/76/773
 PIC16F72/73/737/76/767
 PIC16F870/872/873/873A/876/876A
 PIC16F913
 PIC18C242
 PIC18F242/248/252/258
 PIC18F2220/2221/2320/2321/2331
 PIC18F2410/2420/2431/2455/2480
 PIC18F2510/2515/2520/2525/2550/2580/2585
 PIC18F2610/2620/2680

40-pin PIC



PIC16C65B
 PIC16C662
 PIC16C67
 PIC16C765
 PIC16C77/774
 PIC16F74/747/77/777
 PIC16F871/874/874A/877/877A
 PIC16F914/917
 PIC18F442/452/442/448/452/458
 PIC18F4220/4221
 PIC18F4320/4321/4331
 PIC18F4410/4420/4431/4455/4480
 PIC18F4510/4515/4520/4525/4550/4580/4585
 PIC18F4610/4620/4680

* Use an adaptor for PIC18F4455/4550
 (isolate 23th-pin to 25th-pin of these PIC)